

kajeet. Quick Start Guide


Kajeet SmartSpot®
V400/O55

A POWER BUTTON: Powers the Kajeet SmartSpot on and off and wakes the device from sleep. This button is also used as the 'OK' button when browsing through the menu.

B MENU BUTTON: Used to pull up the menu and switch between menu options.

C SMARTSPOT CHARGING PORT: The AC charger supplied with your SmartSpot connects here.

D STATUS DISPLAY: Provides connection and battery status, network signal, and Wi-Fi network information.



Connecting:

To Your Kajeet SmartSpot

1. Power on the device by holding the power button until you see the 'WELCOME' on the screen.
2. When on the home screen, press the menu button to bring up the device menu.
3. Press the menu button once more to get to "2.4 GHz WIFI INFO." Press power button to select.
4. Note the Wi-Fi network name next to the WiFi symbol (ex. Kajeet SmartSpot ####.)
5. Note the WiFi password next to the lock symbol (ex. smartspot1234.)



Accessing:

Your Kajeet SmartSpot WiFi Name and Password

- Make sure the Kajeet SmartSpot is powered on. If the device has gone to sleep, press the power button once to wake it up.
- On your computer, tablet, mobile phone, or other WiFi enabled device, select the Kajeet SmartSpot WiFi network name (ex. Kajeet SmartSpot ####) from the list of available Wi-Fi networks on your device.
- When prompted for password, enter the WiFi password from step 5 under "Accessing Your Kajeet SmartSpot WiFi Name and Password" (ex. smartspot1234.)
- You should now be connected to the Internet.

To view your device's status and data usage, visit [Kajeet.com/Status](https://kajeet.com/status). For support with your device, please contact Kajeet at (877) 352-5338.